



INDUSTRIES INC.

Home of Mr. Pickup® Truck and SUV Accessories

**2007 GMC 1500 "NEW BODY
STYLE" 1-P Installation sheet
GMC602W-07LD**



Fig 1.



Fig 2. Driver's side



Fig 3 Driver's side Top Bracket



Fig 4 Pass side Tow Hook
Bolts and Frame Horn
Nuts



Fig 5 - Pass side



Fig 6 Driver's side



Fig 7 Pass. Top Bracket

Parts List:

- (1) Grille Guard Assembly
- (2) Top Mounting Brackets
- (2) 7/16" x 1" bolts and Lock Nuts

Installation Procedure:

1. First lift the hood of the truck and remove the plastic grille shroud as shown in fig. 1
2. To install the Top Mounting Brackets – Remove the frame mounting bumper bolts using a 21mm socket. Use the same bolt and install the top mounting brackets as shown in Figures 2 and 3. **NOTE: The top brackets are installed through the bottom opening of the front grille as shown in Fig 3.**

NOTE: Leave the hardware loose at this time to allow for adjustments in the Grille Guard Assembly.

NOTE: The DRIVER's side is shown in the figures 2 and 3.

3. To mount the 1-Piece Grille Guard you must temporarily remove the Tow Hooks. Remove the Tow Hooks by removing the (2) frame mounting bolts (see fig. 4). With the bolts removed pull the Tow Hooks out from the front.
4. Using a second person, install the Grille Guard by sliding the bottom feet of the Grille Guard through the Tow Hook opening. **NOTE: The feet of the Grille Guard must be mounted to the OUTSIDE OF THE FRAME.**

While one person holds the Grille Guard, have the 2nd person slide the Tow Hooks back into place. Use the existing hardware to secure the Grille Guard to the frame. (See Fig. 5 and 6). Leave the hardware loose at this time to allow for adjustments in the Grille Guard Assembly. **NOTE: Yes, there is only suppose to be one bolt on the Driver's side..... NOTE: You may have to provide some alignment relief by trimming the plastic above the Tow Hook opening.**

5. With the bottom feet of the Grille Guard secured, secure the Top Mounting bracket to the Grille Guard using the 7/16's hardware. Leave the hardware loose at this time to allow for adjustments in the Grille Guard Assembly. See fig. 7
6. Align the Grille Guard and tighten up the Tow Hook bolts first. With the bottom feet of the Grille Guard secured, tighten the Top Brackets to the Grille Guard, followed by tightening the Top Bracket frame mounting bolt.

Continue to the back.....

Installation Procedure Continued:

8. With the Grille Guard secured, re-install the plastic shroud as shown in Fig 8

NOTE: MAKE SURE ALL HARDWARE IS TIGHT BEFORE DRIVING THE VEHICLE!



Fig 8 Shroud Install



2007 GMC 1500 “New Body Style” - One Piece Welded

Warranty Statement

All products manufactured by MIH Industries are warranted in the U.S. and Canada for a period of (3) three years (NOTE: Powder Coated products carry a 1 year warranty on the finish) from the date of purchase to the original purchaser. MIH Industries guarantees against manufacturer defects in materials, workmanship, and finish under normal use excluding damage resulting from road hazards, product misuse, improper installation, impairments from collisions, product modifications, product neglect, or vandalism. This three-year warranty applies only to new products and is limited to the repair or replacement of MIH products. Original purchaser must return defective merchandise, along with purchase receipt, to the original place of purchase.

This warranty is not transferable and all liability for incidental or consequential loss or damage or expense, directly or indirectly, arising from labor, freight, inconvenience, removal, installation, or use of the product is excluded unless otherwise prohibited by State or Provincial law(s).